

AVS PREMIUM KEY

AVS PREMIUM KEY



Begin by
removing the
plastic lock from
an AVS Premium
Adaptor



Begin by
removing the
plastic lock from
an AVS Premium
Adaptor




**Take out the AVS
Premium Key**



**Turn it and push
til you hear a click**



Click



**Attach the AVS
Premium Adaptor
to your bag or
basket**



**Attach the bag or
basket to your
AVS Carrier**



Lock it

